

The following guide will help you factory reset your Cisco IP Phone.

FACTORY RESET CISCO IP PHONE (USING KEYPAD)

- 01** Unplug the phone's LAN cable.



- 02** Wait 5 seconds.
- 03** Press and hold **#** button while plugging the phone back in.
- 04** Release the **#** button when the light on the handset blinks red 2 times.
- 05** Press **123456789*0#** in sequence.

After you press these buttons, the phone goes through the factory reset process.

If you press the buttons out of sequence, the phone will power on normally.

The following guide will help you factory reset your Cisco IP Phone.

FACTORY RESET CISCO IP PHONE (USING KEYPAD)

- 01** Unplug the phone's LAN cable.



- 02** Wait 5 seconds.
- 03** Press and hold # button while plugging the phone back in.
- 04** Release the # button when the light on the handset blinks red 2 times.
- 05** Press **123456789*0#** in sequence.

After you press these buttons, the phone goes through the factory reset process.

If you press the buttons out of sequence, the phone will power on normally.